


MAINTENANCE MANUAL

INSTANDHALTUNGSANLEITUNG

MANUEL D'ENTRETIEN


ISTRUZIONI PER LA MANUTENZIONE

**KNOW
HOW**
INSTALLED







✓




1




2




3




4




5




6




7




8




9




2






1




2




3







4



3



Typ 380




Typ 383




3

A


1




2





3



4



i




240.771.00.1


3

B


1






2




3



4






NOTE:

Not applicable for US installations. Flush volume modifications shown are a violation of US law.

DO NOT ATTEMPT!



Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com

