


MAINTENANCE MANUAL


INSTANDHALTUNGSANLEITUNG
MANUEL D'ENTRETIEN
ISTRUZIONI PER LA MANUTENZIONE




970.381.00.0(01)




1




2




3




4




5




6




7



8





9




2

1




2




3


1




2



3




4




4


1




2





3





4



i







Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com